



**NIEUWKOOP**

METEN.NL

# USER MANUAL



## EP6000

CALIBRATION STATION



TO MEASURE  TO KNOW



- Unpack the box and make sure that all parts have been supplied:
  - Plateau with holders
  - 4 tubes (EC4.00, pH4.01, pH6.86 en Demi-water)
  - Clipboard
  - 4 pouches with solutions (EC4.00, pH4.01, pH6.86 en Demi-water)



- Place the tubes in the holders.
- The rear holder can be used for the storage bottle of your sensor . (Note: this bottle is not included!)
- Place the manual with the calibration procedure on the clipboard and put it in the slot in the back of the plateau.
- The supplied pouches with solutions are for single use. After use, please take new pouches or bottles with the same calibration liquid to fill the tubes again.
- The tubes can be emptied after use and rinsed with demi- or distilled water. The solutions do not contain any chemical parts or harmful substances.
- Make sure that you always use fresh solutions.
- The calibration station is ready for use!





TO MEASURE  TO KNOW

**Nieuwkoop BV**

Aalsmeerderweg 249 -S

1432 CM AALSMEER

0297 325836

[info@nieuwkoopbv.nl](mailto:info@nieuwkoopbv.nl)

[www.meten.nl](http://www.meten.nl)



**NIEUWKOOP**