



**NIEUWKOOP**

# QUICK MANUAL



## RG7100

USB DESKTOP INTERFACE CRADLE



TO MEASURE  TO KNOW



## 1. INTRODUCTION

The RG7100 USB Desktop Interface serves as the data transfer link between PC software and non-USB logging products.

- Used with all models that establish PC communication via the 3 contact pins at the rear of your Logger.
- Installs without a proprietary driver - uses the Windows built-in communication interface driver instead.
- Red and green LED's provide feedback about the data exchange between Logger and software.
- The RG7100 Interface Cradle comes with micro-USB to USB-A cable to connect your Interface Cradle to your computer.

## 2. CONNECTING THE INTERFACE CRADLE

Connect the Interface Cradle to your computer using the included USB cable. Please note that the wider part of the Interface Cradle's USB socket is oriented towards the bottom.

Both LED's will briefly blink to indicate your computer has recognized the new device. Windows will now proceed with the setup. This may take a few moments. Once the setup is complete, the Interface Cradle is ready for use.

## 3. USING THE INTERFACE CRADLE

- Open LogTag Analyzer. The green LED will turn on.
- Insert the Logger into the Interface Cradle, contacts first onto the slot and towards the rear. The automatic download starts. The green LED will turn off and the red will turn on to indicate the software is exchanging information with the Logger.
- If the data exchange was successful, the green LED blinks. You can now continue with additional tasks, such as configuring the Logger or hibernating it.
- When the Logger is being configured the red LED turns on again. Once the configuration parameters have been successfully transferred to the Logger, the green LED blinks.
- If an error occurred (for example, if the recorded data could not be downloaded, or the Logger could not be configured) the red LED blinks. The most common causes for this are a low battery, dirty contacts on the Logger or trying to download a while a Logger is still cold.  
You will also see the red LED blinking, if you don't provide a password where required or cancel an operation mid way. In this case, correct the issue and try again.
- Remove the Logger and the green LED will change from 'blinking' to 'on', ready for more Loggers to be inserted.

## 4. LED SIGNALS

ACTION	GREEN	RED	VISUAL
Power-up	simultaneous rapid blinking, 7 times		
USB setup incomplete	off	slow blinking	
No application running	off	off	
Ready for a Logger	solid on	off	
Logger being downloaded	off	solid on	
Download successful	fast blinking	off	
Logger being configured	off	solid on	
Configuration successful	fast blinking	off	
Logger being hibernated	off	solid on	
Hibernation successful	fast blinking	off	
Problems during data exchange	off	fast blinking	



TO MEASURE  TO KNOW

---

**Nieuwkoop BV**

Aalsmeerderweg 249 -S

1432 CM AALSMEER

0297 325836

[info@nieuwkoopbv.nl](mailto:info@nieuwkoopbv.nl)

[www.meten.nl](http://www.meten.nl)



**NIEUWKOOP**